



## Configuring an Opticon OPR-2001 BCR to add the tilde.

	Enter Config Mode
	Set USB Mode
	UK
	All Codes add-on
	Prefix for All Codes
	Add Tilde
	Suffix for All Codes
	Enter
	Exit Config Mode