



Configuring a Cipherlab 1070 BCR to add the tilde.

	Enter Config Mode
	Restore Default Settings
	Activate Keyboard Type
	Type 7
	Type 0
	Validate
	Add Prefix
	Hex 7
	Hex E
	Validate
	Enable Double Scan
	Inter-character Delay
	2
	0
	Validate
	Exit Config Mode